

# Layout no Autocad

ELB13 - Desenho Técnico

# O que são Layouts?

Layouts são ambientes utilizados para simular a folha de papel onde o desenho será impresso e onde serão inseridos margens e carimbos.

Uma das vantagens de se utilizar layouts é a possibilidade de criar vários detalhes do desenho com diferentes fatores de escalas na mesma folha.

# Acionar o LAYOUTWIZARD



## Create Layout - Begin



► Begin

Printer

Paper Size

Orientation

Title Block

Define Viewports

Pick Location

Finish

This wizard provides you the ability to design a new layout.

You can choose a plot device and plot settings, insert a title block and specify a viewport setup.

When you have completed the wizard, the settings will be saved with the drawing.

To modify these settings, you can use the Page Setup dialog from within the layout.

Enter a name for the new layout you are creating.

MinhaImpressao

< Voltar

Avançar >

Cancelar

Create Layout - Printer



Begin

► Printer

Paper Size

Orientation

Title Block

Define Viewports

Pick Location

Finish

Select a configured plotter for the new layout.

Microsoft Print to PDF  
Fax  
AutoCAD PDF (General Documentation).pc3  
AutoCAD PDF (High Quality Print).pc3  
AutoCAD PDF (Smallest File).pc3  
AutoCAD PDF (Web and Mobile).pc3  
Default Windows System Printer.pc3  
DWF6 ePlot.pc3  
DWFx ePlot (XPS Compatible).pc3  
DWG To PDF.pc3  
**PublishToWeb.JPG.pc3**  
PublishToWeb.PNG.pc3

< Voltar

Avançar >

Cancelar

## Create Layout - Paper Size



Begin

Printer

▶ Paper Size

Orientation

Title Block

Define Viewports

Pick Location

Finish

Select a paper size to be used for the layout. The paper sizes available are based on the plot device you selected.

Sun Hi-Res (1600.00 x 1280.00 Pixels) ▼

Enter the paper units for layout "Minhalm Impressao".

Drawing units

☐ Millimeters

☐ Inches

☒ Pixels

Paper size in units

Width: 1601.00 pixels

Height: 1281.00 pixels

< Voltar

Avançar >

Cancelar

## Create Layout - Define Viewports



Begin

Printer

Paper Size

Orientation

Title Block

▶ Define Viewports

Pick Location

Finish

To add viewports to the layout, specify the setup type, scale, and (if applicable) the rows, columns, and spacing.

Viewport setup

☐ None

☒ Single

☐ Std. 3D Engineering Views

☐ Array

Viewport scale:

Scaled to Fit ▾



Rows: 2 Spacing between rows: 0.1

Columns: 2 Spacing between columns: 0.1

< Voltar

Avançar >

Cancelar





# Alterando o Layer para a impressão

